



FIG. I

		•		
	<u>206A</u>	<u>206B</u>	<u>206C</u>	<u>206D</u>
	USER	USER	USER	USER
	205A HIGH-LEVEL OS	205B HIGH-LEVEL OS	205C HIGH-LEVEL OS	205D HIGH-LEVEL OS
210	<u>204A</u>	<u>204B</u>	<u>204C</u>	204D
	208 USER/ HYPVSR I/F	<u> 2010</u>	<u>2040</u>	2010
	OS KERNEL	OS KERNEL	OS KERNEL	OS KERNEL
	HYPER 203 VISOR MGMT			·
	BASE HYPERVISOR (PLIC)			
				<u>201</u>
	HARDWARE LEVEL			
	<u> </u>			

FIG. 2








FIG. 4





FIG. 5A






FIG. 5C




FIG. 5D